


Pack 1421's Pinewood Derby Start Gate


Slide 1 of 5



Basic Start Gate

Pack 1421's Pinewood Derby Start Gate


Slide 2 of 5



Add the spring loaded mechanism (Rubberbands), Screw and Cup holder

Pack 1421's Pinewood Derby Start Gate


Slide 3 of 5



Add the the Starting Gate Trigger, support column and rubberband

Pack 1421's Pinewood Derby Start Gate


Slide 4 of 5



Operate the Gate: Pull Trigger to release start gate

Pack 1421's Pinewood Derby Start Gate

Slide 5 of 5



Reset the Gate: swing the gate handle back in the vertical position