

THE BUG AND BUGETTE (1)

<p>1</p>	<p>A</p> <p>Climbing</p>	<p>B</p> <p>Lock Off - Pull Back</p>
<p>C</p> <p>Paying Out</p>	<p>D1</p> <p>SLOW - In Control</p>	<p>D2</p> <p>FAST - No Control</p>

**CARDIAC ARRESTER (2)
FIGURE OF EIGHT (3)
ANKA DESCENDER (4)**

<p>2</p>		<p>4</p>
<p>E ABSEIL MODE To Anchor</p> <p>Pull Back to Control or Lock Off</p> <p>Attach to Harness using Locking Karabiner</p>	<p>F BELAY MODE Active Rope</p> <p>Control Hand</p> <p>Attach to Harness using Locking Karabiner</p>	<p>G</p> <p>DANGER</p>
<p>H Prussic Knot (Dead Man's Hand)</p>	<p>I CE Approved Mechanical Device</p>	<p>J1</p> <p>SLOW - In Control</p>

<p>J2</p> <p>FAST - No Control</p>	<p>K</p> <p>SLOW - In Control</p>	<p>L</p> <p>DANGER</p>
<p>M</p> <p>DANGER</p>	<p>N</p> <p>DANGER</p>	<p>O</p> <p>DANGER</p>

CARDIAC ARRESTER - USES

<p>P1</p>	<p>P2</p>	<p>P3</p>
------------------	------------------	------------------

Descender



These instructions must be read and understood before this equipment is used.
Please retain this information for future reference.

LANBERIS, GWYNEDD, UNITED KINGDOM, LL55 4EL
e-mail: post@dmmwales.com
http://www.dmmwales.com



F304QA/4/March 2004



DMM
ABSEIL & BELAY EQUIPMENT