
Model # 22583 10' x 20' Pop-Up Canopy



For assembly questions or replacement parts, Please call: Consumer Support 1-800-524-9970



Assembly Instructions

STEP 1

Begin by placing the canopy frame near the setup area. Along with a helper grasp a corner leg of the frame in each hand. While lifting the frame slightly off the ground and stepping backwards, pull the frame apart until your arms are fully extended



STFP 2

Carefully unfold the fabric top and place it over the frame making sure to align the corners of the cover with the corners of the frame.



While taking care not to pinch your fingers, grasp the frame sections marked "Open Here" and push UP until the canopy is fully opened






STEP 4

At the four corners slide the corner slide up until the button "pops" into place as shown When this is done pull the cover corners down snugly and smoothly. Lift the valance over the middle legs and insert the tension hook in the anchor hole. Wrap the T over the cross bar and pull the elastic loop under the cross bar. Insert the T thru the elastic loop to secure the valance. Lift the valance over the middle legs and insert the tension hook in the anchor hole. Wrap the T over the cross bar and pull the elast loop under the cross bar. Insert the T thru the elastic loop to secure the valence





STEP 5


At alternating corners slide the legs your desired height and be sure that the "Snap Pins" are engaged.



STEP 6

Install the pin anchors thru the corner feet.

Note: These are NOT meant for permanent installations and you should never leave your canopy unattended!



Take Down" Instructions

STEP 1

Remove anchors pins, loosen all the "hook & loop" fasteners holding the cover to the frame. Depress the height adjusting "Snap Pins" and slide the legs to their shortest position. Be sure the pins engage



STEP 2

Depress the push button in the corner slides and slide them down the corner legs, while slightly lifting the frame and moving the corners inward









STEP 3

While taking care not to pinch your fingers or the cover, push the corners inwards until the entire frame is collapsed







Care & Cleaning - Warnings

DO NOT expose top to open fire or flame.

DO NOT use barbeque grills, fire pits, deep fryers or smokers undernearth this canopy.

DO NOT use harsh abrasives, bleach or cleaners. Cover may be cleaned with mild soap and water.

IMPORTANT: PLEASE READ CAREFULLY

ShelterLogic has no control over the elements such as wind, rain, snow or ice. This canopy is designed to offer protection from sun, light rain, tree sap, bird droppings etc. It is not designed to hold the loads that can accompany snow, ice or heavy wind or rain. Proper anchoring is the responsibility of the user, as such you should never leave your canopy unattended.

IMPORTANT INFORMATION



READ THIS FIRST!

CUSTOMER ASSISTANCE

For help with assembly, replacement parts, questions or concerns with your ShelterLogic product, call toll free:

1-800-524-9970

Mon - Fri: 8am - 9pm (est) / Sat-Sun: 8am-Noon (est)

ShelterLogic[®],LLC

150 Callendar Road Watertown, CT 06795



IMPORTANT INFORMATION - PRECAUTIONS - CARE & CLEANING

- 1) Inventory all parts before attempting installation.
- 2) Always wear safety glasses when assembling this product.

 Wear gloves when working with tubing, to prevent cuts or abrasions.
- 3) Use product on a level surface
- **4)** Allow six (6) feet from structures such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
- 5) Anchors must be used with all shelters. When erecting shelters, covers should NOT be installed on any product until it has been properly anchored to the ground. Any shelter that is not anchored securely or properly will blow away. ShelterLogic will not be responsible for any shelter that blows away. Proper anchoring for the shelter and the specific conditions are the responsibility of the customer.
- 6) NEVER start the engine of any vehicle or machine in any closed shelter. ShelterLogic vent kits and other vents are not sufficient ventilation for carbon monoxide and other fumes. Special ventilation or an open door should be used at all times for these situations. Any work with paints, cleaning products, etc. may require additional ventilation

- 7) Do Not use barbeque grills, smokers or other flammable equipment under or inside any shelters.
- 8) No snow accumulation should be tolerated on the shelter. Watch out for accumulated snow on the sides. A strong lateral pressure could provoke your shelter to collapse. Shelter is NOT meant to hold heavy snow or ice loads. Brush snow and ice off top with a broom or mop.
- 9) Do Not use harsh abrasives, bleach or cleansers. Cover and walls can be easily cleaned with mild soap and water.
- 10) Periodically check stakes, anchors, covers & tunbuckles to ensure stability of unit, especially following exposure to high winds or heavy rain.
- 11) Daily changes in temperature may cause some condensation in the shelter. A vapor barrier is recommended along with a vent kit to eliminate this problem.
- 12) ShelterLogic Products has no control over the elements such as wind, heavy snow or heavy rain. We cannot be responsible for damage caused by the shelter or to the shelter.
- **13)** Be sure to read the warranty and complete the registration form upon receipt of your order.

THIS CANOPY IS NOT RATED FOR SNOW LOAD AND NOT RETURNABLE IF DAMAGED BY WEATHER



Check inside the larger diameter pipes for other tubes

For Installation Assistance, Parts and Information

ShelterLogic*

CALL TOLL FREE

ShelterLogic^{**}

1-800-524-9970